

CMP 58307-280-100

INSTALLATION

- Insert a flat head screw driver in the small seam between the Upper Clip and Lower Clip. Gently use screw driver to pry apart Upper Clip and Lower Clip by levering screw driver around all sides of the clips (similar to opening a paint can). When screw driver has dislodged Upper Clip, use your hand to pull it the rest of the way off.
- 2. Uninstall existing cleaner bag.
- 3. Slide the fiber fitting of the new Auto Cleaner Bag through the Upper Clip. Install fiber fitting over the Lower Clip, lining up all holes with the Lower Clip's raised circles.
- 4. Slide Upper Clip back down over the fiber fitting and the Lower Clip. Installation is now complete.







