

STATUS	POWER INDICATOR	UV-C INDICATOR	OZONE INDICATOR
REGULAR OPERATION	GREEN	PURPLE	BLUE
OZONE SERVICE DUE	GREEN	PURPLE	YELLOW
UV-C SERVICE DUE	GREEN	YELLOW	BLUE
OZONE ERROR/FAULT	RED	PURPLE	RED
UV-C ERROR/FAULT	RED	RED	BLUE
OZONE SERVICE OVERDUE	YELLOW	PURPLE	BLINKING RED
UV-C SERVICE OVERDUE	YELLOW	BLINKING RED	BLUE
SYSTEM ERROR/FAULT	RED	RED	RED